

When counter on remote swithces and starts to count down take hand held and check air quality around the door (check door on all sides, top and bottom and four corners for leakage of H2O2)

Air Quality hand held reading should be less than 1 PPM to enter room

Step 13: – Check the door for leaks at 30 minutes into the cycle using hand held air quality device

Step 14: When Cycle is complete and lights change to Green the Red Button will flash Green Push the flashing red button to end the cycle.

> Step 15: Check the air quality around the door seal again with the hand held device and record the air quality around the door on the log sheet

> > Step 16: NEXT DAY

Remove tape around door, UNLOCK door, take hand held air quality tester and stick arm in the room with door cracked and record air quality at PPM on log sheet